


freedomRail® EDGE LONG DOOR INSTALLATION GUIDE

REQUIRED TOOLS

• Power Drill



• #2 Phillips Bit



• #2 Screwdriver



SCAN TO LEARN.
MIRA Y APRENDE.


SCAN TO LEARN

For complete installation information including videos to watch and learn visit:


[OrganizedLiving.com/Installation/freedomRailEDGE](https://www.OrganizedLiving.com/Installation/freedomRailEDGE)

INCLUDED PARTS


2x - LONG DOOR



6x - HINGE ASSEMBLY



2x - HANDLE



4x - MACHINE SCREW




12x - WOOD SCREW




ASSEMBLE DOORS

1. Remove all of the product from the carton. Arrange both Doors on a flat, non-marring surface with the large holes facing up.
2. Insert a Hinge into each large hole in the Door. Use a #2 Phillips Bit to drive two Hinge Screws through each Hinge Assembly into the predrilled holes. Do not over tighten.





ADD DOORS TO THE UNIT

1. With the Hinges open, align the top Hinge Plate Screw with the 2nd hole from the top. While holding the Door in place, press firmly and use a #2 Phillips Bit to drive the screw into the Tower Panel.




HINGE PLATE SCREW




2. Align the bottom Hinge Plate Screw with the 2nd hole from the bottom Shelf. While holding the Door in place, press firmly and use a #2 Phillips Bit to drive the screw into the Tower Panel. Now that the Door is in place, press firmly and insert the remaining four Hinge Plate Screws.

3. Follow the same steps to attach the 2nd Door to the other Tower Panel.




ADD HANDLES AND ADJUST HINGES

5. Attach each Handle using the provided 1" Machine Screws with a #2 Screwdriver. Each Door has one handle.




6. Once the Doors are attached and the Handles are installed, the Doors may need to be adjusted to align with each other and the Tower. The Hinge Assembly has 3-way adjustments: **(A)** Front to back. **(B)** Left to Right. **(C)** Top to Bottom.




REMOVING DOORS

1. To remove a Door, push the release button on the back of each Hinge. When a "click" sound is heard, the Door portion of the Hinge has released from the Hinge Plate. Once all the Hinges have been released, remove the Door.



2. To re-attach a Door, insert the hooks on the Hinge Assemblies into the Hinge Plates. Then rotate the Hinge Assembly until it snaps into place.



Contact Us.

Phone: 1-888-674-5484 8 am-5 pm EST Mon-Fri.
Email: customerservice@organizedliving.com
OrganizedLiving.com/Installation

Thank You!

freedomRail EDGE is designed to grow with you. Now that assembly is complete, you can easily adjust any component or add new ones at any time, creating a closet that's truly customized to your lifestyle.